## Guide to 003\_Bluetooth Keyboard

(Turn on by connecting the device to power via the USB connector on the side)

## Connect device (laptop, smartphone, ...) as a normal keyboard

- 1. Under bluetooth settings, search for new devices and connect to "Elsass Keyboard" (Elsass Bluetooth" for old version).
- 2. By pressing 0/1 switches connected to the 8 channels, the unit will send the preset keys to the receiver.

## Change the keyboard setup

The reprogramming of the individual switches is done via Wifi and can be changed from another device than the one connected via Bluetooth.

- 1. On a device (laptop, smartphone, ...) search for wireless networks. Connect to "Elsass Keyboard" or whatever the device has been renamed to, as this can also be changed.
  - a. For some devices, it may be necessary to accept the connection to the network.
- 2. Open any browser (Chrome, Edge, Firefox, ...) and type 192.168.1.1 in the address field.
- 3. By changing the list for the 8 channels and then pressing "Submit" you can specify what the 8 channels activate.
  - a. If you are sitting on a PC with English language, you can select "En" at the top.
- 4. (Requires update to the latest version!): If you want to change the name for Wifi and/or Bluetooth, this is also done via the corresponding boxes however, this requires the device to be restarted, by briefly disconnecting the USB plug and then reconnecting the USB.